

VIGTIGE SIKKERHEDSINSTRUKTIONER

- Montér lysdekorationen på forsvarlig vis da slag, stød og unødigt overlast kan medføre beskadigelse af produktet og/eller ned-sættelse af produktets levetid.
- Ved nedtagning/pakning af dekorationen skal produktet være rent og tørt.
- Denne lysdekoration må ikke forbindes til eller med noget andet produkt.
- Der må kun bruges den transformer, der passer til produktet.
- Produktet må ikke tilsluttes strøm, når den ligger i emballagen.
- Ledning og LED'er til denne dekoration kan ikke udskiftes. Såfremt disse beskadiges, skal produktet kasseres.
- Lysdekorationen er ikke legetøj og placeres uden for børns rækkevidde.

FEJLFINDING

- Er der ingen lys i dekorationen, kontrolleres det om produktet er tændt (ON).
- Ledning og transformer er forbundet korrekt.

AFSKAFFELSE AF PRODUKT

Elektrisk / elektronisk udstyr indeholder materialer, komponenter og stoffer, der kan være skadelige for menneskers sundhed og for miljøet, hvis affaldet ikke håndteres korrekt. Elektrisk / elektronisk udstyr er mærket med den overkrydsede skrælde-spand. Den symboliserer, at elektrisk / elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt. Som slutbruger er det vigtigt, at du afleverer dine udtjente produkter til de ordninger, der er etableret. På denne måde er du med til at sikre, at materialerne genanvendes i overensstemmelse med lovgivningen og ikke unødigt belaster miljøet. Alle kommuner har etableret indsamling-sordninger, hvor kasseret elektrisk/ elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer og andre indsamlingssteder eller blive afhentet direkte fra husholdningerne. Nærmere information kan fås hos kommunens tekniske forvaltning.

IMPORTANT SAFETY INSTRUCTIONS

- Mount and dismount the light decoration properly and carefully, as knocks and jolts may cause damage to the product or reduce the lifetime of the LEDs.
- When taking down and repacking the light decoration, the product must be clean and dry.
- Never put the light decoration in a sealed plastic bag, as condensation may occur and the product will be damaged by moisture.
- This light decoration must be not connected to or with any other product.
- Use only the transformer sold with this product.
- Do not connect the product to the mains, when still in the package.
- Cable and LEDs for this light decoration cannot be replaced. If damaged, the product must be discarded.
- The light decoration is not a toy and should be placed out of reach of small children.

CONTACT

kundeservice@deluxehomeart.com
+45 71 99 19 09

DELUXE HOMELIGHT

Plantinvej 7D
DK-6000 Kolding

FAULT DETECTION

If the product does not light up, please check that:

- the product is turned on (ON)
- cable and transformer is connected correctly

DISPOSAL OF PRODUCT

Electric / electronic equipment contains materials, components and substances that may be harmful for human health as well as for the environment, if not handled correctly. Electric / electronics equipment is marked with a crossed out wheelee bin and means proper disposal of the product is required. As a consumer you can help protect the environment and ensure that the product is recycled in accordance with legislation by disposing of the product properly.



Scan the
QR code for
more product
labeling info